

DAVID CARR

LOCKSMITHS & ALARMS

VC Intercom - Basic User Guide:


Visitor walks up to the entry door station and presses the desired unit button



The buzzer in the unit sounds. The resident then picks up the phone and speaks to the visitor. If the entry request is granted, the resident presses the button for 5 seconds (the button is in the middle of the phone holder). This activates the door release. While the button is pressed, instruct the visitor to push open the door.



When the button is released, the electric strike changes from "open" to "secure" and the door when closed now locks.



Specialising in home security including a complete locksmith Service (including master & restricted key Systems), alarm systems, back to base monitoring, keyless access, CCTV systems, safes (standard and fire resistant).