

# DAVID CARR

---

## LOCKSMITHS & ALARMS

Congratulations on your new 236i Alarm.

If you have any queries, please do not hesitate to contact us on 9389 8543.

The following are a few of the frequently asked questions:

### How do I arm/disarm the alarm?

*Answer: To arm the alarm (to turn on the alarm) enter 4 digit code and then press “#”. To disarm the alarm (to turn off the alarm) enter 4 digit code and then press “#”.*

### How do I arm/disarm the alarm in night/stay mode?

*Answer: If you have your alarm set up for night/stay mode (ie turn on alarm ONLY for down stairs and have alarm unarmed upstairs) then enter “ \* 4 # ” to turn on the stay mode. To disarm the alarm (to turn off the alarm) enter 4 digit code and then press “#”.*

### How do I change a user code?

*Answer: please enter the old code, “\*”, “0”, “#”, then user number (1-5), “#” the new 4 digit code then “#”, the new 4 digit code then “#”, “\*” and “#”. For example: if user number is 1, old code was 1234 and new code was 1111 to change user is: **1234 \* 0 # 1 # 1111 # 1111 # \* #** (please enter without pausing)*

### What does the following mean?

*Green power light flashing – low battery (need to change battery)*

*No green power light – now power (need to check alarm connected to power)*

*Flashing orange service light – phone line issues*

*Flashing numbers in red – press \*1# (to reset system)*

### What do I do when the green power light is flashing “Low battery”?

*Answer: Each alarm system has a back up battery to make sure your alarm operates for approximately 24 to 48 hours in case the power is cut. If the signal is flashing on the screen then you need to replace the back up battery. Cause can be disruption to the power supply or the battery is past it's used by date.*

*Specialising in home security including a complete locksmith Service (including master & restricted key Systems), alarm systems, back to base monitoring, keyless access, CCTV systems, safes (standard and fire resistant).*